

Cleaning

Verosol pleated blinds are anti static and therefore dust and dirt repellent. Avoid positioning in humid areas, contact with water, positioning in extreme heat. In order to keep the pleated blinds in good shape, dusting or vacuuming them twice per year will be sufficient.

Whilst vacuuming, use moderate suction power plus an extension tool with a soft brush side. To prevent stains, do remove dead insects immediately. Ultrasonic cleaning is a possibility in case thorough cleansing is either desirable or indispensable (motorised products excepted). Verosol can supply you with addresses of recognised cleaning firms.

Warranty

Verosol offers a (factory) warranty of 3 years on the end product produced by Verosol. Operating systems and switches carry a 2-year warranty, only if they have been installed and operated in accordance with supplied instructions. The warranty covers both material and production errors. During the warranty period, all recognised errors will be corrected free of charge.

The warranty does not include: wrongful installation, wrongful use, self-made modifications, incorrect cleansing, outdoor use, application of chemicals, caustic materials or any exterior causes such as damage by insects, condensation etc.

Child safety

You should be aware of the fact that small children can get entangled in chains and cords of the window decorating product. In order to minimise the possibility of such an accident, cords should be kept out of reach of babies and small children. A proper way of realising this precaution is a cord cleat (available at your dealer). Install the cord cleat in such a way that the cords are out of reach of the children.

Keep in mind that children might be able to stand on their bedstead or on other furniture pieces in order to reach the cords.



Verosol also has brochures available regarding roller blinds, roman shades and Twin blinds (two transparencies in one product). For detailed information and colour advice, consult the Verosol collection book at your local dealer.

Verosol UK., P.O. Box 146, Westerham TN16 3WJ.
www.verosol.co.uk



Pleated blinds



Vertical blinds



Roller blinds



Curtains



Roman shades



Panel tracks



Venetian blinds

Installation and operating instructions Verosol pleated blinds

- Conservatory
- Skylight

Verosol®

Installation Verosol pleated blind for a conservatory




Installation in the window frame or to the ceiling
Position the supports in line with the tension wires.



Installation on the window frame or on the wall
Install the angle brackets supports in line with the tension wires.




Attach the clip to the corner support by turning 90°.



Hook both the head and bottom rail to the back side of the synthetic support and click the front into the rail.



Tension wires
Tension the tension wires whilst having the blind raised.



Tighten the brake cord (when grip control)
Tension the brake cord. Connect the cord to the little spring. Tighten it to max. 1,5 cm.



Tighten pulling cord (with motorised monocontrol)
Tighten the cords in the middle rail. After operation check the tension of the cords again.

Installation pleated blinds for a skylight




Install one of the side profiles.



Position the top rail in the recess of this profile.



Install the second side profile on the head rail



Attach the second side profile.